

## ➤ DMX512

Channel	Function	Description
CH1	Sum dimmer	R、G、B sum dimmer, linear dimmer, from dark to bright
CH2	R dimmer	R dimmer, linear dimmer, from dark to bright
CH3	G dimmer	G dimmer, linear dimmer, from dark to bright
CH4	B dimmer	B dimmer, linear dimmer, from dark to bright
CH5	W dimmer	W dimmer, linear dimmer, from dark to bright
CH6	Function choose	0—50: strobe and linear dimmer, 51—100: hop, 101—150: gradual, 151—200: pulse change, 201—255: sound control
CH7	Function speed	Function 5CH, speed from slow to fast

## ➤ Current regulation

ITEM	DISPLAY	FUNCTION
1	rL00	Red current (00—99) B、C key revise current limiting size, date increase current decrease
2	gL00	Green current (00—99) B、C key revise current limiting size, date increase current decrease
3	bL00	Blue current (00—99) B、C key revise current limiting size, date increase current decrease