

MINI WASH MOVING HEAD

USER MANUAL



Catalog

| | |
|--|----------|
| Maintaining..... | 1 |
| Statement..... | 1 |
| Caveats..... | 2 |
| Introduction to products..... | 2 |
| Channel control instructions..... | 3 |
| Display control instructions..... | 4 |

Maintaining

1. the Lamps and lanterns should be kept dry, avoid working in moist environment
2. Indirect use will extend the service life of the lamp effectively
3. To obtain the better effect of ventilation and lighting, it is need to pay attention to the regular cleaning of fan and lens
4. Do not use organic solvents to clean the lamp shell, so as not to cause damage

Statement

This product performance in good condition, completely packed, working properly before it is sold. All users should strictly comply with the above stated warnings and instructions. Any damaged caused by human error are not within the company's warranty. Faults and problems which caused from neglect the operation manual is not in the Distributor responsible for range.

This manual for technical are subject to change without further notice.

Caveats

1. In order to ensure the service life of the products, the products should not put on a wet or Water Leakage place, nor in the temperature more than 40 Deg place to work
2. Do not place this product where easily loose or vibration.
3. In order to avoid the risk of electricity, for maintenance please ask professional personnel for help
4. The power supply voltage change should not be more than 10% when Light bulb work , high voltage will shorten the service life of the bulb, low voltage can lower the smooth effect.
5. Lamps and lanterns need sufficient cooling when the power is energized again after use.
6. In order to guarantee the normal use of this product, please read the instructions carefully.

introduction to products

Operating Voltage :AC220V/50Hz

Power consumption:90W

Light source: Jing xin 10 w light bead

Package Weight: 3.800kg (8.381b.)

Package Size: 24cm x 17cm x 17cm (9.45in x 6.69in x 6.69in)

The channel signal:DMX512 port

Strobe: 0-10 Times/Second, adjustable

Dimming: 0%-100% linearly tunable

X-axis:540° 16Bit adjustable

Y-axis:270° 16Bit adjustable

Special function:The program built in a variety of lighting effects, can separate from the console operation.

Optical system:High precision quartz lens combination, make the light loss to the minimum.

Protection: intelligent temperature overheating protection and anti-interference electronic circuit.

14channel control instructions

Our company's products receive international standard DMX512 signal, the detailed content of control are as follows

| Channel | | Function |
|---------|---------|--------------------------|
| 1 | 0-255 | The level of (X) |
| 2 | 0-255 | Horizontal adjustment |
| 3 | 0-255 | Vertical (Y) |
| 4 | 0-255 | Vertical adjustment |
| 5 | 0-255 | Speed |
| 6 | 0-7 | No effect |
| | 8-134 | Dimming |
| | 135-239 | Strobe from slow to fast |
| | 240-255 | Light |
| 7 | 0=255 | Color selection |
| | | Color jump |
| 8 | 0-255 | Color selection |
| | | Color gradient |
| 9 | 0-255 | Color speed |
| 10 | 0-255 | Red |
| 11 | 0-255 | Green |
| 12 | 0-255 | Blue |
| 13 | 0-255 | white |
| 14 | 150-255 | Reset |

Display control instructions

Press the MODE/ESC key to enter the menu settings and Press the ENTER key to enter the menu sub menu,press the UP or DOWN key to choose sub-menu items, press the ENTER key to confirm the normal work, the objective function that is as follows:

7 little shook his head



