

DMX Channel Summary - 17 Channels Mode		
Channel	Value	Function
1.	0-255	Total Dimmer
2.	0-255	Red Dimmer
3.	0-255	Green Dimmer
4.	0-255	Blue Dimmer
5.	0-255	White Dimmer
6.	0-255	Total Brightness Control
7.	0-255	X - axis Rotates
8.	0-255	Y - axis Rotates
9.	0-255	Pan Fine
10.	0-255	Tilt Fine
11.	0-255	X/Y - axis Speed Control
12.	0-255	Zoom
13.	0-255	Strobe
14.	0-255	Auto Mode
15.	0-255	Speed Control - Auto Mode
16.	250-255	Reset
17.	0	Blank (spare)

DMX Channel Summary - 11 Channels Mode		
Channel	Value	Function
1.	0-255	Total Dimmer
2.	0-255	Red Dimmer
3.	0-255	Green Dimmer
4.	0-255	Blue Dimmer
5.	0-255	White Dimmer
6.	0-255	Total Brightness Control
7.	0-255	X - axis Rotates
8.	0-255	Y - axis Rotates
9.	0-255	Zoom
10.	0-255	Strobe
11.	0-255	Blank (spare)