

System Menu

DMX 8 Channels&Functions:

1CH	Main Dimmer	R、G、B 、W Dimmer, Linear Dimmer, From Dark to bright
2CH	Strobe	R、G、B 、 W Strobe, from slow to fast
3CH	Function Selection	0—50: DMX 8CH control; 51—100: Hopping; 101—150: fade; 151—200: Slow change; 201—255: sound control
4CH	Function Rate	RGBW Mixing Function speed , From slow to fast
5CH	Red dimmer	Red dimmer, Linear dimmer, from dar to bright
6CH	Green dimmer	Green dimmer, Linear dimmer, From dark to bright
7CH	Blue dimmer	Blue dimmer, Linear dimmer, From dark to bright
8CH	White dimmer	White dimmer, Linear dimmer, From dark to bright