

DMX CHS	CH value	Function
1CH X rotation	000-255	X rotation 0°-540°
2CH X fine adjustment	000-255	X fine adjustment
3CH Y rotation	000-255	Y rotation 0°-270°
4CH Y fine adjustment	000-255	Y fine adjustment
5CH X/Y Speed	000-255	XY speed from fast to slow
6CH LED 60W Dimmer	000-255	From dark to bright
7CH Strobe	0-5	ON
	6-249	Strobe from slow to fast
	250-255	ON
8CH 7Color + White	0-9	White
	10-29	Red
	30-49	Green
	50-69	Blue
	70-89	Yellow
	90-109	Purple
	110-129	Aqua
	130-149	Cambridge blue
150-255	Rainbow Effect(slow to fast)	
9CH Focus	000-255	Focus, from near to far
10CH 6 Gobos + White	0-19	White
	20-39	Gobo 1
	40-59	Gobo 2
	60-79	Gobo 3
	80-99	Gobo 4
	100-119	Gobo 5
	120-139	Gobo 6
	140-255	Gobo rotating CW and CCW from slow to fast)
11CH Gobo self-rotation	0-19	No function
	20-139	Gobo self-rotating clockwise from slow to fast
	140-255	Gobo self-rotating counter-clockwise from slow to fast
12CH 8 Gobos + White	0-9	White
	10-19	Gobo 1
	20-39	Gobo 2